

Charleston Hardware Company

4236 Pace Street, North Charleston SC 29405

843 958 8626 contact@chco.biz

Charlestonhardware.com

Step by step instructions for the installation of tubular entry door sets

- Drill the thru bores 5-1/2" on center.
- The top deadbolt thru bore 2-1/8" (so the silver deadbolt screw plate will nest into the bore).
- Drill the bottom latch thru bore 1" or use the existing 2-1/8" bore.
- Edge bores are standard.
- Install the latch.
- Extend the deadbolt and install with the opening for the cylinder tail piece down.
- Install the exterior plate first.
- Insert the doorknob spindle from that side centering the doorknob.
- Place the thick ring and deadbolt on the plate.
- On the interior side hold the flat silver plate over the bore so that it is centered with the tail piece extending through.
- Position the plate so the doorknob and cylinder align correctly.
- Insert the long screws into the back of the cylinder until it is snug.
- Align the interior plate with the tail of the cylinder and doorknob.
- Pre-drill the screw holes through the plates and secure the plates with the screws.
- Contact us if you need additional guidance 843 958 8626
- Stand back and admire your work!

